

**AAR Manual of Standards and Recommended Practices
Intermodal Equipment Manual**

ALPHABETICAL TABLE OF CONTENTS

Standard	Subject	Page
M-985	Bad Order Device for Identification of Defective Hitches	I[M-985]217
RP-899	Car Owner's Manual for the Inspection and Maintenance of Double-Stack Container Cars	I[RP-899]285
M-930	Containers for Domestic Intermodal Service	I[M-930]19
RP-851	Double-Stack Container Cars	I[RP-851]241
M-929	Grease for Lubrication of Trailer Hitches on Flatcars	I[M-929]17
M-928	Highway Trailer Hitches for Freight Cars	I[M-928]1
M-928A	Highway Trailer Hitches for Freight Cars with 90,000-lb Maximum Gross vehicle Weight Capacity	I[M-928A]9
S-732	Inspection and Lubrication of Trailer Hitches on Flatcars	I[S-732]227
M-998	Intermodal Container Support and Interbox Connector (IBC) Securement System for Freight Cars	I[M-998]219
M-952	Intermodal Container Support and Securement System for Freight Cars	I[M-952]207
RP-852	Intermodal Equipment Cars	I[RP-852]245
M-933	Intermodal Trailer and Container Securement	I[M-933]163
M-935	Standard Operating Procedures for Intermodal Securement	I[M-935]193
M-966	TOFC Portable Bridge Plates	I[M-966]213
RP-853	Trailer Repair and Modification	I[RP-853]249
M-931	Trailers for Intermodal Service	I[M-931]93

IMPLEMENTED 08/01/2018

**AAR Manual of Standards and Recommended Practices
Intermodal Equipment Manual**

NUMERICAL TABLE OF CONTENTS

Standard	Subject	Page
M-928	Highway Trailer Hitches for Freight Cars	I[M-928]1
M-928A	Highway Trailer Hitches for Freight Cars with 90,000-lb Maximum Gross vehicle Weight Capacity	I[M-928A]9
M-929	Grease for Lubrication of Trailer Hitches on Flatcars	I[M-929]17
M-930	Containers for Domestic Intermodal Service	I[M-930]19
M-931	Trailers for Intermodal Service	I[M-931]93
M-933	Intermodal Trailer and Container Securement	I[M-933]163
M-935	Standard Operating Procedures for Intermodal Securement	I[M-935]193
M-952	Intermodal Container Support and Securement System for Freight Cars	I[M-952]207
M-966	TOFC Portable Bridge Plates	I[M-966]213
M-985	Bad Order Device for Identification of Defective Hitches	I[M-985]217
M-998	Intermodal Container Support and Interbox Connector (IBC) Securement System for Freight Cars	I[M-998]219
RP-851	Double-Stack Container Cars	I[RP-851]241
RP-852	Intermodal Equipment Cars	I[RP-852]245
RP-853	Trailer Repair and Modification	I[RP-853]249
RP-899	Car Owner's Manual for the Inspection and Maintenance of Double-Stack Container Cars	I[RP-899]285
S-732	Inspection and Lubrication of Trailer Hitches on Flatcars	I[S-732]227

IMPLEMENTED 08/01/2018