

**AAR Manual of Standards and Recommended Practices
Locomotives and Locomotive Interchange Equipment**

**TABLE OF CONTENTS IN
ALPHABETICAL SEQUENCE**

Subject	Standard	Page
27-Point Control Plug and Receptacle	S-512	M[S-512]3
Access Doors to Light Boxes for Road Number, Headlight, or Warning Lights—Outside Cab	RP-5107	M[RP-5107]337
Air Brake Exhaust Piping	RP-508	M[RP-508]257
Air Flow Indicators	S-5597	M[S-5597]219
Automatic Engine Start/Stop System	S-5502	M[S-5502]133
Axle Nomenclature Arrangement—Locomotives	RP-5523	M[RP-5523]399
Basic Brake Design Data for Freight Locomotives	RP-5209	M[RP-5209]369
Brake Shoe Unflanged	RP-518	M[RP-518]269
Brake Shoes—High-Friction Composition Type for Locomotives	RP-599	M[RP-599]325
Brake Shoes—Metal Type	RP-5596	M[RP-5596]405
Braking Ratios for Locomotives	RP-509	M[RP-509]261
Calibration Procedure for AFM-Type Air Flow Indicators	S-5598	M[S-5598]223
Color Code for Identifying Fluids on Locomotive	RP-512	M[RP-512]263
Cushion Pad—Locomotive Cab Door Frame	RP-5115	M[RP-5115]339
Designation of Sides and Ends of Locomotives	RP-514	M[RP-514]265
Diesel Locomotive Control Stand for New Locomotives	RP-5132	M[RP-5132]355
Door Closure Bar—Locomotive Cab	RP-5117	M[RP-5117]341
Dynamic Braking Control	S-5018	M[S-5018]121
Flexible Hinge Guard on Locomotive Cab Door	RP-5120	M[RP-5120]343
Fuel Additive Evaluation Procedure	RP-503	M[RP-503]225
Lead-Acid Batteries and Compartments	RP-590	M[RP-590]313
Locomotive Alerter Requirements	S-5513	M[S-5513]211
Locomotive Cab Seats	RP-5104	M[RP-5104]331
Locomotive Cab Window Glazing Material	S-5101	M[S-5101]129
Locomotive Crashworthiness Requirements	S-580	M[S-580]11
Locomotive Dynamic Brake Status Reporting	S-5509	M[S-5509]151
Locomotive Electronics System Architecture	S-590	M[S-590]19
Locomotive Event Recorder Download Standard	S-5512	M[S-5512]203
Locomotive Fueling Interface	RP-5503	M[RP-5503]371
Locomotive Horn Valve Handle with Soft, Resilient-Type Rubber Cover	RP-5122	M[RP-5122]345
Locomotive Interchange Agreement	S-5500	M[S-5500]1
Locomotive Rating Train/Track Resistance	RP-548	M[RP-548]277
Locomotive System Integration Operating Display	S-591	M[S-591]83
Locomotive-Based Top-of-Rail Friction Control Application Systems	S-5511	M[S-5511]187
Main Reservoir Equalizing End Hose Coupling	RP-5595	M[RP-5595]403

IMPLEMENTED 03/29/2008

**AAR Manual of Standards and Recommended Practices
Locomotives and Locomotive Interchange Equipment**

Subject	Standard	Page
Minimum Requirements for Main Reservoir System on New and Rebuilt Diesel-Electric, Electric, and Gas Turbine Locomotives of 800-hp Capacity and Greater	RP-546	M[RP-546]275
Multiple Unit Pneumatic Brake Equipment for Locomotives	S-5529	M[S-5529]215
Padded Sun Visor in Locomotive Cab—Engineer’s Side Only	RP-5124	M[RP-5124]347
Performance Requirements for Diesel Electric Locomotive Fuel Tanks	S-5506	M[S-5506]137
Plate L—Locomotive Diagram for Interchange Service	S-5510	M[S-5510]183
Rating for Specific Fuel Consumption of Diesel Electric Locomotives	RP-589	M[RP-589]311
Recessed Windshield Wiper Valve, Train-Order Light Switch, and Flush-Mounted Train-Order Light	RP-5126	M[RP-5126]349
Remote Control Locomotives	S-5507	M[S-5507]139
Rounded Cab Window Latch in Locomotive Cabs	RP-5127	M[RP-5127]351
Rounding All Possible Exposed Convex Edges and Corners	RP-5128	M[RP-5128]353
Spark Arrester	RP-557	M[RP-557]279
Testing Electrical Components	RP-545	M[RP-545]271
Typical 26-L Type Brake Equipment Piping Diagrams for Locomotives	RP-505	M[RP-505]239
Windshield Wiper Motor Handle with Soft-Rubber-Type Grip	RP-5136	M[RP-5136]365
Windshield Wiper Motor Protective Cover	RP-5137	M[RP-5137]367
Wire and Cable Insulating Material	RP-588	M[RP-588]309
Wire and Cable Insulating Material—Moisture-Resisting Jacketed	RP-586	M[RP-586]303
Wire and Cable Insulating Material—Silicone Rubber Insulated	RP-587	M[RP-587]307
Wiring and Cable Specification	RP-585	M[RP-585]283

IMPLEMENTED 03/29/2008

**AAR Manual of Standards and Recommended Practices
Locomotives and Locomotive Interchange Equipment**

**TABLE OF CONTENTS IN
NUMERICAL SEQUENCE**

Standard	Subject	Page
RP-503	Fuel Additive Evaluation Procedure	M[RP-503]225
RP-505	Typical 26-L Type Brake Equipment Piping Diagrams for Locomotives	M[RP-505]239
RP-508	Air Brake Exhaust Piping	M[RP-508]257
RP-509	Braking Ratios for Locomotives	M[RP-509]261
RP-512	Color Code for Identifying Fluids on Locomotive	M[RP-512]263
RP-514	Designation of Sides and Ends of Locomotives	M[RP-514]265
RP-518	Brake Shoe Unflanged	M[RP-518]269
RP-545	Testing Electrical Components	M[RP-545]271
RP-546	Minimum Requirements for Main Reservoir System on New and Rebuilt Diesel-Electric, Electric, and Gas Turbine Locomotives of 800-hp Capacity and Greater	M[RP-546]275
RP-548	Locomotive Rating Train/Track Resistance	M[RP-548]277
RP-557	Spark Arrester	M[RP-557]279
RP-585	Wiring and Cable Specification	M[RP-585]283
RP-586	Wire and Cable Insulating Material—Moisture-Resisting Jacketed	M[RP-586]303
RP-587	Wire and Cable Insulating Material—Silicone Rubber Insulated	M[RP-587]307
RP-588	Wire and Cable Insulating Material	M[RP-588]309
RP-589	Rating for Specific Fuel Consumption of Diesel Electric Locomotives	M[RP-589]311
RP-590	Lead-Acid Batteries and Compartments	M[RP-590]313
RP-599	Brake Shoes—High-Friction Composition Type for Locomotives	M[RP-599]325
RP-5104	Locomotive Cab Seats	M[RP-5104]331
RP-5107	Access Doors to Light Boxes for Road Number, Headlight, or Warning Lights—Outside Cab	M[RP-5107]337
RP-5115	Cushion Pad—Locomotive Cab Door Frame	M[RP-5115]339
RP-5117	Door Closure Bar—Locomotive Cab	M[RP-5117]341
RP-5120	Flexible Hinge Guard on Locomotive Cab Door	M[RP-5120]343
RP-5122	Locomotive Horn Valve Handle with Soft, Resilient-Type Rubber Cover	M[RP-5122]345
RP-5124	Padded Sun Visor in Locomotive Cab—Engineer’s Side Only	M[RP-5124]347
RP-5126	Recessed Windshield Wiper Valve, Train-Order Light Switch, and Flush-Mounted Train-Order Light	M[RP-5126]349
RP-5127	Rounded Cab Window Latch in Locomotive Cabs	M[RP-5127]351
RP-5128	Rounding All Possible Exposed Convex Edges and Corners	M[RP-5128]353
RP-5132	Diesel Locomotive Control Stand for New Locomotives	M[RP-5132]355
RP-5136	Windshield Wiper Motor Handle with Soft-Rubber-Type Grip	M[RP-5136]365
RP-5137	Windshield Wiper Motor Protective Cover	M[RP-5137]367
RP-5209	Basic Brake Design Data for Freight Locomotives	M[RP-5209]369
RP-5503	Locomotive Fueling Interface	M[RP-5503]371
RP-5523	Axle Nomenclature Arrangement—Locomotives	M[RP-5523]399

IMPLEMENTED 03/29/2008

**AAR Manual of Standards and Recommended Practices
Locomotives and Locomotive Interchange Equipment**

Standard	Subject	Page
RP-5595	Main Reservoir Equalizing End Hose Coupling	M[RP-5595]403
RP-5596	Brake Shoes—Metal Type	M[RP-5596]405
S-512	27-Point Control Plug and Receptacle	M[S-512]3
S-580	Locomotive Crashworthiness Requirements	M[S-580]11
S-590	Locomotive Electronics System Architecture	M[S-590]19
S-591	Locomotive System Integration Operating Display	M[S-591]83
S-5018	Dynamic Braking Control	M[S-5018]121
S-5101	Locomotive Cab Window Glazing Material	M[S-5101]129
S-5500	Locomotive Interchange Agreement	M[S-5500]1
S-5502	Automatic Engine Start/Stop System	M[S-5502]133
S-5506	Performance Requirements for Diesel Electric Locomotive Fuel Tanks	M[S-5506]137
S-5507	Remote Control Locomotives	M[S-5507]139
S-5509	Locomotive Dynamic Brake Status Reporting	M[S-5509]151
S-5510	Plate L—Locomotive Diagram for Interchange Service	M[S-5510]183
S-5511	Locomotive-Based Top-of-Rail Friction Control Application Systems	M[S-5511]187
S-5512	Locomotive Event Recorder Download Standard	M[S-5512]203
S-5513	Locomotive Alerter Requirements	M[S-5513]211
S-5529	Multiple Unit Pneumatic Brake Equipment for Locomotives	M[S-5529]215
S-5597	Air Flow Indicators	M[S-5597]219
S-5598	Calibration Procedure for AFM-Type Air Flow Indicators	M[S-5598]223

IMPLEMENTED 03/29/2008